

# FLEET MANAGEMENT CHECKLIST

**Premier**<sup>®</sup>  
TRAILER LEASING

## Tire Maintenance:

- **Check tire pressure:** Check tire pressure regularly and adjust as needed to ensure optimal performance and fuel efficiency. Use a tire pressure gauge to measure the pressure accurately. This should be done by the driver before taking the trailer out of the yard.
- **Inspect tire tread:** Check tire tread regularly to ensure that it is within acceptable limits. Use a tire tread depth gauge to measure the depth of the tread. Replace tires before the tread wear is below the Department of Transportation minimum 2/32nds of an inch.
- **Check for damage:** Regularly inspect tires for signs of damage, such as cuts, punctures, or bulges. Replace any damaged tires promptly to ensure safety and prevent further damage.
- **Tire vendor:** Consider having a tire vendor perform weekly yard checks to find and fix flats, low inflaters and damage.

